

SKUナンバー	製品名	JAN/EAN (JANコードに対応するSKUナンバー)	原産国及び製造事業者	推定販売期間	推定販売台数	推定製造期間	推定輸入期間
23943, 23944, 23945, 23946, 23947, 23948, 23949, 23950, 23951, 23952, 25245, 25246, 25247, 25248, 25967, 25968, 25969, 25970, 25971, 25972, 25973, 25974, 26430, 26431, 26766, 26767, 29819, 29820, 33317, 33318, 24850, 24851, 24858, 24859, 251168-13, 251168-23, 251168-63	ACOUSTIMASS® 5 SERIES IV POWERED SPEAKER SYSTEM			1998 - 2005		1998 - 2005	1998 - 2005
264830-1119, 264830-2123, 264830-212R, 264830-2223, 264830-222R, 264830-2323, 264830-232R, 264830-4123, 264830-412R, 264830-4223, 264830-422R, 264830-4323, 264830-432R, 29275, 29277, 29278, 29279, 29280, 31590, 31597, 31598, 31599, 31600, 330374-1100, 33834, 346838-1100, 346838-1110, 346838-1120, 346838-1130, 346839-1100, 346839-1110, 346839-1120, 346839-1700, 346839-1710, 346839-1720, 34971, 35157, 352569-2100, 352569-210R, 352569-2200, 352569-220R, 352569-4100, 352569-410R, 352569-4200, 352569-420R, 353198-0010, 35359, 35360, 35361, 355381-2120, 355381-2220, 355381-2320, 355381-4120, 355381-4220, 355381-4320, 360727-2100, 360731-2100, 361655-1110, 361655-1120, 629824-2100, 629825-2100, 264831-1139, 264831-2119, 264831-213S, 264831-2219, 264831-223S, 31133	ACOUSTIMASS® 6 III HOME ENT. SYSTEM (2090から6091のデータコードのみ)	4969929015471 (29275)		2002 - 1 April 2007		2002 - 1 April 2006	2002 - 1 April 2007
264880-1119, 29283, 29284, 29285, 29286, 29287, 29288, 31591, 31592, 31601, 31602, 31603, 31604, 33571, 34972, 35158, 35362, 35373, 264881-1139, 264881-1239, 31134, 31135	ACOUSTIMASS® 10 III HOME ENT. SYSTEM		4969929013064 (29283) 4969929013071 (29284)	2002 - 1 April 2007	11,582	2002 - 1 April 2006	2002 - 1 April 2007
21363, 21364, 21365, 21366, 21367, 21368, 21369, 21370, 21371, 21372, 22857, 22858, 23423, 23424, 23425, 23426, 30017, 36697, 37483, 37484	ACOUSTIMASS® 15 HOME THEATER SPEAKER SYSTEM		4969929003966 (21368) 4969929009661 (21367)	1998 - 2006	18,629	1998 - 1 April 2006	1998 - 2006
264910-1119, 29291, 29292, 29293, 29294, 29295, 29296, 31593, 31594, 31605, 31606, 31607, 31608, 33573, 34983, 35159, 35374, 35375, 193854-001, 193854-002, 193854-131C, 23206, 23207, 264911-1139, 264911-1239, 31136, 31137, 356439-211S, 356439-221S	ACOUSTIMASS® 15 II HOME ENT. SYSTEM (2090から6091のデータコードのみ)			2002 - 1 April 2007		2002 - 1 April 2006	2002 - 1 April 2007
264910-1129, 29659, 29660, 31595, 31596, 33574, 39098, 264911-1149, 264911-1249, 31138, 31139	ACOUSTIMASS® 16 HOME ENT. SYSTEM		4969929012630 (29659)	2002 - 1 April 2007	1,100	2002 - 1 April 2006	2002 - 1 April 2007
10052, 10053, 10054, 10055, 10056, 10057, 10058, 10059, 10063, 10064, 17996, 17997, 18803, 18804, 18850, 18851, 18938, 20184, 20185, 21157, 21158, 21159, 21160, 21161, 21162, 21235, 21236, 21237, 21238, 22725, 22726, 22727, 22728, 22729, 22730, 22731, 22732, 22733, 22734, 22735, 22736, 23417, 23418, 23419, 23420, 24334, 24335, 25049, 25050, 25051, 25052, 25053, 25054, 25055, 25056, 25235, 25236, 25961, 25962, 25963, 25964, 25965, 25966, 26432, 26433, 26753, 26754, 26863, 26864, 26888, 26889, 26890, 26891, 26892, 26893, 26894, 27140, 27141, 27142, 27143, 27152, 27153, 27154, 27155, 30019, 30020, 33019, 33319, 33320, 178715-1119, 178715-1219, 178715-2219, 178715-6119, 178715-6219, 181363-13, 181363-23, 181363-63, 197983-1119, 22905, 22906, 23575, 23576	ACOUSTIMASS® 20 POWERED SPEAKER SYSTEM			1996 - 2005		1996 - 2005	1996 - 2005
11105, 11106, 17190, 17209, 17210, 19042, 20459	COMPANION™ CS-6 POWERED SPEAKER SYSTEM		4969929008374 (17190)	1995 - 1998	420	1995 - 1998	1995 - 1998

9	11069, 15130, 15883, 15884, 15885, 15886, 19153, 19154, 9484, 9485, 9486, 9487, 9488, 9489, 9490, 9491, 9492, 9493, 11070, 11452, 11453, 11454, 11456, 11457, 11483, 11484, 11485, 11486, 172273-1119, 172273-1219, 172273-6219, 172274-13, 172274-23, 172274-63, 18805, 18806, 19595, 349185-0010, 9474, 9475, 9476, 9477, 9478, 9479, 9480, 9481, 9482, 9483, 9498, 9503	LIFESTYLE® 5 SERIES II POWERED SPEAKER SYSTEM	
10	19560, 19562, 19563, 19564, 19565, 19566, 19567, 19568, 19569, 19570, 19571, 20960, 20961, 20962, 21670, 21671, 22859, 22860, 189879-131C, 20406, 20407, 20408, 20658, 20659, 20660, 21436, 21437	LIFESTYLE® 8 POWERED SPEAKER SYSTEM	4969929002990 (19560)
11	10050, 10051, 10174, 10627, 10628, 10629, 10630, 10676, 10677, 11114, 11115, 24273, 8782, 8783, 8784, 8786, 8960, 9249, 9250, 9251, 9253, 10229, 11079, 11489, 11490, 11491, 11492, 175552-23, 175552-33, 18408, 18409, 18410, 18411, 18418, 18419, 187694-131C, 187694-231C, 187694-631C, 187696-1119, 187696-1219, 187696-2119, 187696-6119, 187696-6219, 191170-131C, 191170-231C, 191170-631C, 197284-001, 21423, 21424, 251714-001, 252184-001, 252184-006, 253284-006, 253859-001, 253859-002, 253859-006, 9527, 9930	LIFESTYLE® 12 POWERED SPEAKER SYSTEM	4969929004949 (10677)
12	10052, 10053, 10054, 10055, 10056, 10057, 10058, 10059, 10063, 10064, 17996, 17997, 18803, 18804, 18850, 18851, 18938, 25049, 25050, 25051, 25052, 25053, 25054, 25055, 25056, 27140, 27141, 27142, 27143, 178715-1119, 178715-1219, 178715-2219, 178715-6119, 178715-6219, 181363-13, 181363-23, 181363-63, 197983-1119, 22905, 22906, 23575, 23576	LIFESTYLE® 20 POWERED SPEAKER SYSTEM	
13	17450, 17451, 17452, 17453, 17456, 17457, 17458, 17459, 17460, 17461, 18955, 18956, 18957, 18958, 18959, 18960, 18963, 18964, 22940, 18408, 18409, 18410, 18411, 18418, 18419, 187694-131C, 187694-231C, 187694-631C, 187696-1119, 187696-1219, 187696-2119, 187696-6119, 187696-6219, 191170-131C, 191170-231C, 191170-631C, 197284-001, 21423, 21424, 251714-001, 252184-001, 252184-006, 253284-006, 253859-001, 253859-002, 253859-006	LIFESTYLE® 25 POWERED SPEAKER SYSTEM	
14	20453, 20454, 20456, 20457, 20546, 20547, 20964, 20965, 21239, 21240, 21241, 21242, 21351, 21352, 23189, 23413, 23414, 23415, 23416, 193134-131C, 193134-2313, 193134-231C, 193134-631C, 20542, 20543, 21532, 21533	LIFESTYLE® 30 POWERED SPEAKER SYSTEM	
15	22737, 22738, 22739, 22740, 22741, 22742, 22743, 22744, 22745, 22746, 22747, 22748, 24336, 24337, 25237, 25238, 26755, 26756, 26895, 26896, 26897, 26898, 26899, 26900, 26901, 26902, 27156, 27157, 27159	LIFESTYLE® 50 POWERED SPEAKER SYSTEM	
16	11069, 15130, 15883, 15884, 15885, 15886, 19153, 19154, 9484, 9485, 9486, 9487, 9488, 9489, 9490, 9491, 9492, 9493, 11070, 11452, 11453, 11454, 11456, 11457, 11483, 11484, 11485, 11486, 172273-1119, 172273-1219, 172273-6219, 172274-13, 172274-23, 172274-63, 18805, 18806, 19595, 349185-0010, 9474, 9475, 9476, 9477, 9478, 9479, 9480, 9481, 9482, 9483, 9498, 9503	POWERED ACOUSTIMASS® 5 SERIES III SPEAKER SYSTEM	

USA, Mexico and
Ireland
Bose Corporation

1995 - 1999	2	1995 - 1999	1995 - 1999
1998 - 2000	3,241	1998 - 2000	1998 - 2000
1994 - 1999	216	1994 - 1999	1994 - 1999
1996 - 2005		1996 - 2005	1996 - 2005
1996 - 2000		1996 - 2000	1996 - 2000
1996 - 1999		1996 - 1999	1996 - 1999
1999 - 2004		1999 - 2004	1999 - 2004
1995 - 1999	"LIFESTYLE® 5 SERIES II POWERED SPEAKER SYSTEM" (No. 9)を参照。No.9 及びNo.16 は同一製品ですが、製品ラベル上異なる製品名で販売されていました。	1995 - 1999	1995 - 1999

17	23933, 23934, 23935, 23936, 23937, 23938, 23939, 23940, 23941, 23942, 23943, 23944, 23945, 23946, 23947, 23948, 23949, 23950, 23951, 23952, 25219, 25220, 25221, 25222, 25245, 25246, 25247, 25248, 25967, 25968, 25969, 25970, 25971, 25972, 25973, 25974, 26126, 26127, 26430, 26431, 26766, 26767, 29819, 29820, 33317, 33318, 24850, 24851, 24858, 24859, 251168-13, 251168-23, 251168-63	POWERED ACOUSTIMASS® 5 SERIES IV SPEAKER SYSTEM	
18	19560, 19562, 19563, 19564, 19565, 19566, 19567, 19568, 19569, 19570, 19571, 20960, 20961, 20962, 21670, 21671, 22859, 22860, 189879-131C, 20406, 20407, 20408, 20658, 20659, 20660, 21436, 21437	POWERED ACOUSTIMASS® 8 SPEAKER SYSTEM	4969929002990 (19560)
19	24465, 24466, 24467, 24468, 24469, 24470, 24471, 24472, 24473, 24474, 24475, 24476, 26783, 26784, 27035, 27036, 27697, 27698, 31365, 252879-2109, 252879-6109, 252879-6209, 263062, 26807, 26808	POWERED ACOUSTIMASS® 8 SERIES II SPEAKER SYSTEM	4969929009746 (24470)
20	10050, 10051, 10174, 10416, 10627, 10628, 10629, 10630, 10676, 10677, 11114, 11115, 11259, 11260, 11261, 11262, 11263, 11264, 11265, 11266, 11267, 11268, 11269, 11270, 16865, 16866, 16867, 16868, 16869, 16870, 19097, 19098, 20538, 20539, 20540, 20541, 20956, 20957, 20958, 20959, 24273, 25257, 25258, 8782, 8783, 8784, 8786, 8799, 8960, 9249, 9250, 9251, 9253, 9254, 10229, 11079, 11489, 11490, 11491, 11492, 175552-23, 175552-33, 9527, 9930	POWERED ACOUSTIMASS® 9 SPEAKER SYSTEM	4969929004949 (10677)
21	10052, 10053, 10054, 10055, 10056, 10057, 10058, 10059, 10063, 10064, 17996, 17997, 18803, 18804, 18850, 18851, 18938, 20184, 20185, 21157, 21158, 21159, 21160, 21161, 21162, 21235, 21236, 21237, 21238, 22725, 22726, 22727, 22728, 22729, 22730, 22731, 22732, 22733, 22734, 22735, 22736, 23417, 23418, 23419, 23420, 24334, 24335, 25049, 25050, 25051, 25052, 25053, 25054, 25055, 25056, 25235, 25236, 25961, 25962, 25963, 25964, 25965, 25966, 26432, 26433, 26753, 26754, 26863, 26864, 26888, 26889, 26890, 26891, 26892, 26893, 26894, 27140, 27141, 27142, 27143, 27152, 27153, 27154, 27155, 30019, 30020, 33019, 33319, 33320, 178715-1119, 178715-1219, 178715-2219, 178715-6119, 178715-6219, 181363-13, 181363-23, 181363-63, 197983-1119, 22905, 22906, 23575, 23576	POWERED ACOUSTIMASS® 20 SPEAKER SYSTEM	
22	10050, 10051, 10174, 10627, 10628, 10629, 10630, 10676, 10677, 11114, 11115, 17450, 17451, 17452, 17453, 17456, 17457, 17458, 17459, 17460, 17461, 18955, 18956, 18957, 18958, 18959, 18960, 18963, 18964, 22940, 24273, 8782, 8783, 8784, 8786, 8960, 9249, 9250, 9251, 9253, 18408, 18409, 18410, 18411, 18418, 18419, 187694-131C, 187694-231C, 187694-631C, 187696-1119, 187696-1219, 187696-2119, 187696-6119, 187696-6219, 191170-131C, 191170-231C, 191170-631C, 197284-001, 21423, 21424, 251714-001, 252184-001, 252184-006, 253284-006, 253859-001, 253859-002, 253859-006	POWERED ACOUSTIMASS® 25 SPEAKER SYSTEM	4969929004949 (10677)

1998 -2005		1998 -2005	1998 -2005
1998 - 2000	"LIFESTYLE® 8 POWERED SPEAKER SYSTEM" (No. 10)参照。No.10及びNo.18は同一製品ですが、製品ラベル上異なる製品名で販売されていました。	1998 - 2000	1998 - 2000
2000 - 2004	2,961	2000 - 2004	2000 - 2004
1994 - 1998	"LIFESTYLE® 12 POWERED SPEAKER SYSTEM" (No. 11)参照。No.11, No.20及びNo.22は同一製品ですが、製品ラベル上異なる製品名で販売されていました。	1994 - 1998	1994 - 1998
1996 - 2005		1996 - 2005	1996 - 2005
1996 - 2000	"LIFESTYLE® 12 POWERED SPEAKER SYSTEM" (No. 11)参照。No.11, No.20及びNo.22は同一製品ですが、製品ラベル上異なる製品名で販売されていました。	1996 - 2000	1996 - 2000

23	196564-1119K, 196564-1129, 196564-1129F, 196564-1129K, 196564-1219K, 196564-1229, 196564-1229F, 196564-1229K, 196564-6119F, 196564-6119K, 196564-6129, 196564-6129K, 196564-6219F, 196564-6219K, 196564-6229, 196564-6229F, 196564-6229K, 22534, 22535, 22536, 22537, 22538, 22539, 22540, 22541, 22542, 22543, 22544, 22545, 22546, 22547, 22548, 22549, 22550, 22551, 22552, 22553, 22554, 22555, 22556, 22557, 24330, 24331, 24332, 24333, 25025, 25026, 25027, 25028, 25029, 25030, 25031, 25032, 25033, 25034, 25035, 25036, 25037, 25038, 25039, 25040, 25223, 25224, 25225, 25226, 25227, 25228, 25229, 25230, 26076, 26077, 26079, 27136, 27137, 27138, 27139, 27144, 27145, 27146, 27147, 31363, 33193, 196564-1119, 196564-1219, 196564-1219F, 196564-6119, 196564-6219, 23913, 23914, 23915, 23916, 23917, 23918, 23919, 23920, 24763, 263064	POWERED ACOUSTIMASS® 25 SERIES II SPEAKER SYSTEM	4969929003973 (22538) 4969929008725 (22550)	1999 - 2004	11,982	1999 - 2004	1999 - 2004
24	193141-1119, 193141-1219, 193141-6219, 20453, 20454, 20456, 20457, 20544, 20545, 20546, 20547, 20964, 20965, 21213, 21214, 21215, 21216, 21217, 21218, 21219, 21220, 21221, 21222, 21223, 21224, 21239, 21240, 21241, 21242, 21351, 21352, 23189, 23413, 23414, 23415, 23416, 23431, 23432, 23433, 23434	POWERED ACOUSTIMASS® 30 SPEAKER SYSTEM		1996 - 2001		1996 - 2001	1996 - 2001
25	22558, 22559, 22560, 22561, 22562, 22563, 22564, 22565, 22566, 22567, 22568, 22569, 22737, 22738, 22739, 22740, 22741, 22742, 22743, 22744, 22745, 22746, 22747, 22748, 24328, 24329, 24336, 24337, 250128-1119K, 250128-1219K, 250128-6119K, 250128-6219K, 25041, 25042, 25043, 25045, 25046, 25047, 25048, 25231, 25232, 25233, 25234, 25237, 25238, 26080, 26081, 26755, 26756, 26895, 26896, 26897, 26898, 26899, 26900, 26901, 26902, 27148, 27149, 27150, 27151, 27156, 27157, 27159, 23921, 23922, 23923, 23924, 23925, 23926, 23927, 23928, 24749, 24750, 24756, 250128-6119, 250128-6219, 25728, 263061, 193134-131C, 193134-2313, 193134-231C, 193134-631C, 20542, 20543, 21532, 21533	POWERED ACOUSTIMASS® 30 SERIES II SPEAKER SYSTEM		1999 - 2004		1999 - 2004	1999 - 2004
26	25273, 25274, 25276, 25278, 28115, 29223, 255219-1209, 263063, 27095	POWERED ACOUSTIMASS® 800 SPEAKER SYSTEM		2000 -2003		2000 -2003	2000 -2003
27	22137, 24164, 24506, 197743-1219, 22253	POWERED ACOUSTIMASS® 900 SPEAKER SYSTEM		1998 - 2000		1998 - 2000	1998 - 2000